

## Backflow Assembly (BFA) Models

Manufacturer	Models	Type
	288A--MO D-M2	
	DCV	
	FDFDF	
	M825	
	MISSING INFO	
WATTS	8A	ATMOSPHERIC VACUUM BREAKER ASSEMBLY
WATTS	007DCA	DOUBLE CHECK DETECTOR ASSEMBLY
WATTS	007DCDA	DOUBLE CHECK DETECTOR ASSEMBLY
CONBRACO	2 1/2DCDA	DOUBLE CHECK DETECTOR ASSEMBLY
AMES	2000DCA	DOUBLE CHECK DETECTOR ASSEMBLY
AMES	3000	DOUBLE CHECK DETECTOR ASSEMBLY
AMES	3000B	DOUBLE CHECK DETECTOR ASSEMBLY
AMES	3000CIV	DOUBLE CHECK DETECTOR ASSEMBLY
AMES	3000DCD A	DOUBLE CHECK DETECTOR ASSEMBLY
AMES	3000-DC DC	DOUBLE CHECK DETECTOR ASSEMBLY
AMES	3000-G-D CDC	DOUBLE CHECK DETECTOR ASSEMBLY
AMES	3000SE	DOUBLE CHECK DETECTOR ASSEMBLY
AMES	3000SE-A	DOUBLE CHECK DETECTOR ASSEMBLY
AMES	3000SS	DOUBLE CHECK DETECTOR ASSEMBLY
WILKINS	350ADA	DOUBLE CHECK DETECTOR ASSEMBLY
WILKINS	350DA	DOUBLE CHECK DETECTOR ASSEMBLY
WILKINS	350DAG	DOUBLE CHECK DETECTOR ASSEMBLY
CONBRACO	3DCDA	DOUBLE CHECK DETECTOR ASSEMBLY
CONBRACO	40-600-C 3	DOUBLE CHECK DETECTOR ASSEMBLY
CONBRACO	40-600-E3	DOUBLE CHECK DETECTOR ASSEMBLY
CONBRACO	40-60A-C 3	DOUBLE CHECK DETECTOR ASSEMBLY
CONBRACO	40-60A-E 3	DOUBLE CHECK DETECTOR ASSEMBLY
CONBRACO	40-60C-C 3	DOUBLE CHECK DETECTOR ASSEMBLY
CONBRACO	40-60C-E	DOUBLE CHECK DETECTOR ASSEMBLY

	3	
CONBRACO	40-60E-C 3	DOUBLE CHECK DETECTOR ASSEMBLY
CONBRACO	40-60E-E 3	DOUBLE CHECK DETECTOR ASSEMBLY
CONBRACO	40-60G-C 3	DOUBLE CHECK DETECTOR ASSEMBLY
CONBRACO	40-60G-E 3	DOUBLE CHECK DETECTOR ASSEMBLY
WILKINS	450DAG	DOUBLE CHECK DETECTOR ASSEMBLY
CONBRACO	4DCDA	DOUBLE CHECK DETECTOR ASSEMBLY
WATTS	709DCA	DOUBLE CHECK DETECTOR ASSEMBLY
WATTS	709DCDA	DOUBLE CHECK DETECTOR ASSEMBLY
WATTS	770DCDA	DOUBLE CHECK DETECTOR ASSEMBLY
WATTS	772DCDA	DOUBLE CHECK DETECTOR ASSEMBLY
WATTS	774DCDA	DOUBLE CHECK DETECTOR ASSEMBLY
WATTS	774XDCA A	DOUBLE CHECK DETECTOR ASSEMBLY
FEBCO	805DC	DOUBLE CHECK DETECTOR ASSEMBLY
FEBCO	805YR	DOUBLE CHECK DETECTOR ASSEMBLY
FEBCO	806DDC	DOUBLE CHECK DETECTOR ASSEMBLY
FEBCO	856	DOUBLE CHECK DETECTOR ASSEMBLY
FEBCO	856DCDA	DOUBLE CHECK DETECTOR ASSEMBLY
FEBCO	856YD	DOUBLE CHECK DETECTOR ASSEMBLY
FEBCO	876	DOUBLE CHECK DETECTOR ASSEMBLY
FEBCO	876V	DOUBLE CHECK DETECTOR ASSEMBLY
WILKINS	950DA	DOUBLE CHECK DETECTOR ASSEMBLY
WILKINS	950DC	DOUBLE CHECK DETECTOR ASSEMBLY
WILKINS	950DDC	DOUBLE CHECK DETECTOR ASSEMBLY
WILKINS	DCDA	DOUBLE CHECK DETECTOR ASSEMBLY
AMES	DCDC	DOUBLE CHECK DETECTOR ASSEMBLY
HERSEY	DDC	DOUBLE CHECK DETECTOR ASSEMBLY
HERSEY	DDCII	DOUBLE CHECK DETECTOR ASSEMBLY
CLA-VAL	D2	DOUBLE CHECK VALVE ASSEMBLY
WATTS	007	DOUBLE CHECK VALVE ASSEMBLY
WATTS	007M1	DOUBLE CHECK VALVE ASSEMBLY
WATTS	007M1PC QT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	007M1QT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	007M2	DOUBLE CHECK VALVE ASSEMBLY

WATTS	007M2PC QT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	007M2QT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	007M3QT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	007NRS	DOUBLE CHECK VALVE ASSEMBLY
WATTS	007QT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	007SSM1 PCQT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	007SSM1 QT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	007SSPC QT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	007SSQT	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	1/2DC	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	2 1/2DC	DOUBLE CHECK VALVE ASSEMBLY
AMES	2000B	DOUBLE CHECK VALVE ASSEMBLY
AMES	2000CIV	DOUBLE CHECK VALVE ASSEMBLY
AMES	2000DC	DOUBLE CHECK VALVE ASSEMBLY
AMES	2000-DC	DOUBLE CHECK VALVE ASSEMBLY
AMES	2000GDC	DOUBLE CHECK VALVE ASSEMBLY
AMES	2000-G-D C	DOUBLE CHECK VALVE ASSEMBLY
AMES	2000SE	DOUBLE CHECK VALVE ASSEMBLY
AMES	2000SS	DOUBLE CHECK VALVE ASSEMBLY
AMES	2000SS- M	DOUBLE CHECK VALVE ASSEMBLY
BUCKNER	24100	DOUBLE CHECK VALVE ASSEMBLY
BUCKNER	24100/25	DOUBLE CHECK VALVE ASSEMBLY
BUCKNER	24101	DOUBLE CHECK VALVE ASSEMBLY
BUCKNER	24101/25	DOUBLE CHECK VALVE ASSEMBLY
BUCKNER	24102	DOUBLE CHECK VALVE ASSEMBLY
BUCKNER	24102/25	DOUBLE CHECK VALVE ASSEMBLY
BUCKNER	24103	DOUBLE CHECK VALVE ASSEMBLY
BUCKNER	24103/25	DOUBLE CHECK VALVE ASSEMBLY
BUCKNER	24104	DOUBLE CHECK VALVE ASSEMBLY
BUCKNER	24104/25	DOUBLE CHECK VALVE ASSEMBLY
WILKINS	350	DOUBLE CHECK VALVE ASSEMBLY
WILKINS	350G	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	3DC	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	40-100-02	DOUBLE CHECK VALVE ASSEMBLY

CONBRACO	40-100-03	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-100-05	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-103-02	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-104-02	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-104-03	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-104-99 T	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-104-A2	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-104-A2 T	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-104-T C2	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-105-02	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-105-99 T	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-105-A2	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-105-A2 T	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-105TC 2	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-106-02	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-106-99 T	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-106-A2	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-106-A2 T	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-107-02	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-107-99 T	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-107-A2	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-107-A2 T	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-108-02	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-108-99 T	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-108-A2	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-108-A2 T	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-109-02	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-109-03	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-109-05	DOUBLE CHECK VALVE ASSEMLBY
CONBRACO	40-10A-02	DOUBLE CHECK VALVE ASSEMLBY

CONBRACO	40-10A-03	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	40-10A-05	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	40-10A-06	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	40-10C-02	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	40-10C-03	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	40-10C-05	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	40-10C-06	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	40-10E-02	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	40-10E-03	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	40-10E-06	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	40-10G-02	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	40-10G-03	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	40-10G-06	DOUBLE CHECK VALVE ASSEMBLY
WILKINS	450G	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	4DC	DOUBLE CHECK VALVE ASSEMBLY
WILKINS	550	DOUBLE CHECK VALVE ASSEMBLY
WILKINS	550A	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	6DC	DOUBLE CHECK VALVE ASSEMBLY
WATTS	700	DOUBLE CHECK VALVE ASSEMBLY
WATTS	709	DOUBLE CHECK VALVE ASSEMBLY
WATTS	709BB	DOUBLE CHECK VALVE ASSEMBLY
WATTS	709BV	DOUBLE CHECK VALVE ASSEMBLY
WATTS	709DC	DOUBLE CHECK VALVE ASSEMBLY
WATTS	709DCVA	DOUBLE CHECK VALVE ASSEMBLY
WATTS	709DDC	DOUBLE CHECK VALVE ASSEMBLY
WATTS	709M2QT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	709NRS	DOUBLE CHECK VALVE ASSEMBLY
WATTS	709QT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	709QT-F DA	DOUBLE CHECK VALVE ASSEMBLY
WATTS	770	DOUBLE CHECK VALVE ASSEMBLY
WATTS	770QT-F DA	DOUBLE CHECK VALVE ASSEMBLY
WATTS	772	DOUBLE CHECK VALVE ASSEMBLY

WATTS	774	DOUBLE CHECK VALVE ASSEMBLY
WATTS	774X	DOUBLE CHECK VALVE ASSEMBLY
WATTS	775QT	DOUBLE CHECK VALVE ASSEMBLY
FEBCO	805	DOUBLE CHECK VALVE ASSEMBLY
FEBCO	805Y	DOUBLE CHECK VALVE ASSEMBLY
FEBCO	805YB	DOUBLE CHECK VALVE ASSEMBLY
FEBCO	805YBV	DOUBLE CHECK VALVE ASSEMBLY
FEBCO	805YD	DOUBLE CHECK VALVE ASSEMBLY
FEBCO	805YDC	DOUBLE CHECK VALVE ASSEMBLY
FEBCO	805YDM	DOUBLE CHECK VALVE ASSEMBLY
FEBCO	850	DOUBLE CHECK VALVE ASSEMBLY
FEBCO	850A	DOUBLE CHECK VALVE ASSEMBLY
FEBCO	850U	DOUBLE CHECK VALVE ASSEMBLY
FEBCO	870	DOUBLE CHECK VALVE ASSEMBLY
FEBCO	870V	DOUBLE CHECK VALVE ASSEMBLY
WILKINS	950	DOUBLE CHECK VALVE ASSEMBLY
WILKINS	950A	DOUBLE CHECK VALVE ASSEMBLY
WILKINS	950X	DOUBLE CHECK VALVE ASSEMBLY
WILKINS	950XL	DOUBLE CHECK VALVE ASSEMBLY
WILKINS	950XLD`	DOUBLE CHECK VALVE ASSEMBLY
WILKINS	950XLT	DOUBLE CHECK VALVE ASSEMBLY
WILKINS	950XLU	DOUBLE CHECK VALVE ASSEMBLY
GRINNELL	B1	DOUBLE CHECK VALVE ASSEMBLY
GRINNELL	B2	DOUBLE CHECK VALVE ASSEMBLY
ORION	BDC	DOUBLE CHECK VALVE ASSEMBLY
CLA-VAL	DC	DOUBLE CHECK VALVE ASSEMBLY
RAINBIRD	DC100R	DOUBLE CHECK VALVE ASSEMBLY
AMES	DCA	DOUBLE CHECK VALVE ASSEMBLY
RAINBIRD	DCA-075 R	DOUBLE CHECK VALVE ASSEMBLY
RAINBIRD	DCA-100- R	DOUBLE CHECK VALVE ASSEMBLY
RAINBIRD	DCA-150- R	DOUBLE CHECK VALVE ASSEMBLY
RAINBIRD	DCA-200 R	DOUBLE CHECK VALVE ASSEMBLY
RAINBIRD	DCQT	DOUBLE CHECK VALVE ASSEMBLY
RAINBIRD	DC-QT-00 0	DOUBLE CHECK VALVE ASSEMBLY
RAINBIRD	DC-QT-07	DOUBLE CHECK VALVE ASSEMBLY

	5	
RAINBIRD	DCQT100	DOUBLE CHECK VALVE ASSEMBLY
RAINBIRD	DC-QT100	DOUBLE CHECK VALVE ASSEMBLY
RAINBIRD	DC-QT-100	DOUBLE CHECK VALVE ASSEMBLY
RAINBIRD	DCQT150	DOUBLE CHECK VALVE ASSEMBLY
RAINBIRD	DC-QT-150	DOUBLE CHECK VALVE ASSEMBLY
RAINBIRD	DC-QT-200	DOUBLE CHECK VALVE ASSEMBLY
HERSEY	DDC-II	DOUBLE CHECK VALVE ASSEMBLY
HERSEY	E-1	DOUBLE CHECK VALVE ASSEMBLY
HERSEY	FDC	DOUBLE CHECK VALVE ASSEMBLY
HERSEY	FDC II	DOUBLE CHECK VALVE ASSEMBLY
WATTS	SS007M1QT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	SS007M3QT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	U007M1APCQT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	U007M1AQT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	U007M1PCQT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	U007M1QT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	U007M2AQT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	U007M2QT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	U007PCQT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	U007QT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	U007SSPCQT	DOUBLE CHECK VALVE ASSEMBLY
WATTS	U007SSQT	DOUBLE CHECK VALVE ASSEMBLY
	Y PATTERN	DOUBLE CHECK VALVE ASSEMBLY
CONBRACO	20-504-02	PRESSURE VACUUM BREAKER ASSEMBLY
CONBRACO	40-503-02	PRESSURE VACUUM BREAKER ASSEMBLY
CONBRACO	40-505-02	PRESSURE VACUUM BREAKER ASSEMBLY

CONBRACO	40-506-02	PRESSURE VACUUM BREAKER ASSEMBLY
CONBRACO	40-507-02	PRESSURE VACUUM BREAKER ASSEMBLY
CONBRACO	40-508-02	PRESSURE VACUUM BREAKER ASSEMBLY
WILKINS	420	PRESSURE VACUUM BREAKER ASSEMBLY
WILKINS	720A	PRESSURE VACUUM BREAKER ASSEMBLY
FEBCO	760	PRESSURE VACUUM BREAKER ASSEMBLY
FEBCO	765	PRESSURE VACUUM BREAKER ASSEMBLY
FEBCO	765-2	PRESSURE VACUUM BREAKER ASSEMBLY
FEBCO	766	PRESSURE VACUUM BREAKER ASSEMBLY
WATTS	800CM	PRESSURE VACUUM BREAKER ASSEMBLY
WATTS	800CM QT	PRESSURE VACUUM BREAKER ASSEMBLY
WATTS	800M QT	PRESSURE VACUUM BREAKER ASSEMBLY
WATTS	800M2QT	PRESSURE VACUUM BREAKER ASSEMBLY
WATTS	800M3QT	PRESSURE VACUUM BREAKER ASSEMBLY
WATTS	800M4FR	PRESSURE VACUUM BREAKER ASSEMBLY
WATTS	800M4QT	PRESSURE VACUUM BREAKER ASSEMBLY
WATTS	800MC	PRESSURE VACUUM BREAKER ASSEMBLY
WATTS	800QT	PRESSURE VACUUM BREAKER ASSEMBLY
AMES	A200	PRESSURE VACUUM BREAKER ASSEMBLY
CONBRACO	PVB	PRESSURE VACUUM BREAKER ASSEMBLY
FLOMATIC	PVB-FLO	PRESSURE VACUUM BREAKER ASSEMBLY
WATTS	007QTS	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009M00Q TRPZ	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009M1	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009M1PC QT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009M1QT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009M2	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009M2PC QT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009M2QT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009M3QT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009MI	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009MZQT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009NRS	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009PCQT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009QT	REDUCED PRESSURE BACKFLOW ASSEMBLY

WATTS	009QTM1	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009QTS	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009SSM1 PCQT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	009SSM1 QT	REDUCED PRESSURE BACKFLOW ASSEMBLY
BUCKNER	24000	REDUCED PRESSURE BACKFLOW ASSEMBLY
BUCKNER	24000/25	REDUCED PRESSURE BACKFLOW ASSEMBLY
BUCKNER	24001	REDUCED PRESSURE BACKFLOW ASSEMBLY
BUCKNER	24001/25	REDUCED PRESSURE BACKFLOW ASSEMBLY
BUCKNER	24002	REDUCED PRESSURE BACKFLOW ASSEMBLY
BUCKNER	24002/25	REDUCED PRESSURE BACKFLOW ASSEMBLY
BUCKNER	24003	REDUCED PRESSURE BACKFLOW ASSEMBLY
BUCKNER	24003/25	REDUCED PRESSURE BACKFLOW ASSEMBLY
BUCKNER	24004	REDUCED PRESSURE BACKFLOW ASSEMBLY
BUCKNER	24004/25	REDUCED PRESSURE BACKFLOW ASSEMBLY
WILKINS	375DA	REDUCED PRESSURE BACKFLOW ASSEMBLY
AMES	4000	REDUCED PRESSURE BACKFLOW ASSEMBLY
AMES	4000B	REDUCED PRESSURE BACKFLOW ASSEMBLY
AMES	4000BM2	REDUCED PRESSURE BACKFLOW ASSEMBLY
AMES	4000-RP	REDUCED PRESSURE BACKFLOW ASSEMBLY
AMES	4000SS	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-200-02	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-200-03	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-200-05	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-201-02	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-201-99 5	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-201-A2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-201-A2 S	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-202-02	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-202-99 T	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-202-A2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-202-A S2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-203-02	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-203-08	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-203-99 5	REDUCED PRESSURE BACKFLOW ASSEMBLY

CONBRACO	40-203-A2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-203-A2 S	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-204-02	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-204-99 T	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-204-A2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-204-A2 S	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-204-A2 U	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-204-A2 Z	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-204-T C2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-204-T CU	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-205-02	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-205-24	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-205-99 T	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-205-A2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-205-A2 S	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-205-A2 U	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-205-A2 Z	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-205-T2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-205-T C2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-205-T CU	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-206-99 T	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-206-A2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-206-A2 U	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-206-A2 Z	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-206-T2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-207-02	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-207-99 5	REDUCED PRESSURE BACKFLOW ASSEMBLY

CONBRACO	40-207-A2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-207-A2 U	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-207-A2 Z	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-208-02	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-208-99 T	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-208-A2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-208-A2 U	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-208-A2 Z	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-208-T2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-208-T2 U	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-208-T2 Z	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-209-02	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-209-03	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-209-05	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-20A-02	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-20A-03	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-20A-05	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-20C-0 2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-20C-0 3	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-20C-0 5	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-20E-02	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-20E-03	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-20G-0 2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CONBRACO	40-20G-0 3	REDUCED PRESSURE BACKFLOW ASSEMBLY
WILKINS	475G	REDUCED PRESSURE BACKFLOW ASSEMBLY
WILKINS	475V	REDUCED PRESSURE BACKFLOW ASSEMBLY
WILKINS	575	REDUCED PRESSURE BACKFLOW ASSEMBLY
WILKINS	575A	REDUCED PRESSURE BACKFLOW ASSEMBLY
HERSEY	6C	REDUCED PRESSURE BACKFLOW ASSEMBLY
HERSEY	6-C	REDUCED PRESSURE BACKFLOW ASSEMBLY

HERSEY	6CM	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	825	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	825D	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	825Y	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	825YA	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	825YAR	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	825YBV	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	825Y-BV	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	825YD	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	825YR	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	825YRP	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	835	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	835B	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	835B-2	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	845	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	860	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	860U	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	880	REDUCED PRESSURE BACKFLOW ASSEMBLY
FEBCO	880V	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	900	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	909	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	909CW	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	909HW	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	909M1	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	909M1QT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	909MI	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	909MOD	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	909NR	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	909QT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	909QTM1	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	909QTM1	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	909RP	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	957	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	957N	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	967	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	967N	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	967Z	REDUCED PRESSURE BACKFLOW ASSEMBLY
WILKINS	975	REDUCED PRESSURE BACKFLOW ASSEMBLY
WILKINS	975A	REDUCED PRESSURE BACKFLOW ASSEMBLY

WILKINS	975MS	REDUCED PRESSURE BACKFLOW ASSEMBLY
WILKINS	975XL	REDUCED PRESSURE BACKFLOW ASSEMBLY
WILKINS	975XLBMS	REDUCED PRESSURE BACKFLOW ASSEMBLY
WILKINS	975XLMS	REDUCED PRESSURE BACKFLOW ASSEMBLY
WILKINS	975XLSE	REDUCED PRESSURE BACKFLOW ASSEMBLY
WILKINS	975XLSEU	REDUCED PRESSURE BACKFLOW ASSEMBLY
WILKINS	975XLU	REDUCED PRESSURE BACKFLOW ASSEMBLY
WILKINS	975XLV	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	990	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	990QT-FDA	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	992	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	994	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	995QT	REDUCED PRESSURE BACKFLOW ASSEMBLY
HERSEY	FRP	REDUCED PRESSURE BACKFLOW ASSEMBLY
HERSEY	FRP-11	REDUCED PRESSURE BACKFLOW ASSEMBLY
HERSEY	FRP2	REDUCED PRESSURE BACKFLOW ASSEMBLY
HERSEY	FRPII	REDUCED PRESSURE BACKFLOW ASSEMBLY
HERSEY	FRP-II	REDUCED PRESSURE BACKFLOW ASSEMBLY
CLA-VAL	RP-1	REDUCED PRESSURE BACKFLOW ASSEMBLY
CLA-VAL	RP-2	REDUCED PRESSURE BACKFLOW ASSEMBLY
CLA-VAL	RP-2 1685401A	REDUCED PRESSURE BACKFLOW ASSEMBLY
CLA-VAL	RP-4	REDUCED PRESSURE BACKFLOW ASSEMBLY
RAINBIRD	RPA-075-R	REDUCED PRESSURE BACKFLOW ASSEMBLY
RAINBIRD	RPA-100-R	REDUCED PRESSURE BACKFLOW ASSEMBLY
FLOMATIC	RPZ	REDUCED PRESSURE BACKFLOW ASSEMBLY
FLOMATIC	RPZE	REDUCED PRESSURE BACKFLOW ASSEMBLY
FLOMATIC	RPZII	REDUCED PRESSURE BACKFLOW ASSEMBLY
FLOMATIC	RPZIIIE	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	SS009QT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	U009APCQT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	U009AQT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	U009M1APCQT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	U009M1A	REDUCED PRESSURE BACKFLOW ASSEMBLY

	QT	
WATTS	U009M1QT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	U009M2APCQT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	U009M2AQT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	U009M2QT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	U009SSPCQT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	U009SSQT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	U090QT	REDUCED PRESSURE BACKFLOW ASSEMBLY
WATTS	U909HWQT	REDUCED PRESSURE BACKFLOW ASSEMBLY
CLA-VAL	18-4	REDUCED PRESSURE DETECTOR ASSEMBLY
CONBRACO	40-700-C3	REDUCED PRESSURE DETECTOR ASSEMBLY
CONBRACO	40-700-E3	REDUCED PRESSURE DETECTOR ASSEMBLY
AMES	5000	REDUCED PRESSURE DETECTOR ASSEMBLY
HERSEY	6CMDA	REDUCED PRESSURE DETECTOR ASSEMBLY
FEBCO	806	REDUCED PRESSURE DETECTOR ASSEMBLY
FEBCO	806YD	REDUCED PRESSURE DETECTOR ASSEMBLY
FEBCO	826YD	REDUCED PRESSURE DETECTOR ASSEMBLY
WILKINS	975 DA	REDUCED PRESSURE DETECTOR ASSEMBLY
CLA-VAL	RD7LY	REDUCED PRESSURE DETECTOR ASSEMBLY
VIKING	P-1	SINGLE DETECTOR CHECK VALVE
WATTS	008PCQT	SPILL RESISTANT PRESSURE VACUUM BREAKER ASSEMBLY
CONBRACO	SVB	SPILL RESISTANT PRESSURE VACUUM BREAKER ASSEMBLY